



FITTING TIPS FOR MADE TO MEASURE PANELS

Thank you very much for ordering our Made to Measure Secondary Glazing panels. While Ecoease secondary glazing is very easy to fit, the following information following will guide you through:

- Before you remove the protective film on your panel offer it up to the window to check it will fit.
- To ensure the magnetic tapes adhere properly to your window frame, wipe your frame a degreaser e.g. methylated spirits or similar.
- **Slowly** remove the protective film on the side of the panel with the tapes attached - the one which face the glass of your window. If you remove the film too quickly you will create static electricity which will attract dust and other minute debris. Leave the film on the surface which faces the room for the moment.
- If the steel tapes (the ones with the blue backing) have moved during transit realign them with the magnetic tape and remove the blue backing film. **Never** attempt to remove the steel strips and stick them to your window as you will not get them to line up properly if you do!
- You can now offer the panel up to your frame. It can help to use your window cill to balance the panel allowing you to “walk” it up to the window.
- When your Secondary Glazing pane is in place, press with your thumb along the white PVC edging to ensure it is securely fixed all around.
- Finally, slowly remove the film from the front of the panel.

