



Fitting Instructions for The City 480, City 680, The Deene and Cherwell Canopies

2-piece Flat Canopy

STEP 1

- A: Mark centre-line onto door frame.
- B: Mark spirit level line – do not cover any weep holes.

STEP 2

- C: Mark centre-line on canopy soffit.
- D: 1st operative to offer soffit to wall marrying up all marks.

STEP 3

- E: 2nd operative to drill 6.5x120mm tight to both ends (central)
- F: Fix using 7.5x100mm concrete fixing with oversize mudguard washer.

STEP 4

- G: Use spirit level to check canopy is level on projection.
- H: Pack between back of canopy and wall where required. Tighten/slacken fixing if necessary.

STEP 5

- I: Once canopy is all level, put 2 fixings (1 into each brick course) adjacent to all baffles and at both ends of canopy.
 - J: Use spirit level to double check (loosen & pack if necessary)
- (please note if fixing to Frog Hall Brick ensure fixing goes into solid part of brickwork)



STEP 6

K: Mark and pre-drill roof part of canopy along back flange at 600mm centres, using 6.5mm drill bit. Holes to be equally spaced and at same height.

STEP 7

L: Offer roof to soffit – pin fasteners in roof to meet holes in soffit.

M: Drill (6.5x120mm bit) through pre-drilled holes (K) and into brickwork. Fix using 7.5x100mm concrete fixing with washers to receive caps.

STEP 8

N: Before fixing tight, packers may be necessary between roof flange and brickwork to prevent canopy going out of level.

O: Silicone mastic seal roof flange/wall and soffit/brickwork in appropriate colour.

P: Cover all visible screw heads with colour matching caps, or lead flash into brickwork and over flange (optional).



the
glazingshop

Tel: 01536 446395 Email: sales@theglazingshop.co.uk Web: www.theglazingshop.co.uk

Unit 13, Earlstrees Court, Earlstrees Industrial Estate, Corby, Northamptonshire, NN17 4AX