



## **Fitting Instructions for The New Lerwick & Eaton Mono- Pitch Canopy with Brackets**

### **STEP 1**

- A: Mark centre-line over door frame.
- B: Mark spirit level line – do not cover any weep holes.

### **STEP 2**

- C: Mark centre-line on canopy soffit.
- D: 1<sup>st</sup> operative to offer soffit to wall marrying up with marks.

### **STEP 3**

- E: 2<sup>nd</sup> operative to drill 6.5x120mm tight to both ends (central) Fix using 7.5x100mm concrete fixing. Ensure fixing into most solid part of wall/brickwork.

### **STEP 4**

- F: Use spirit level to check canopy is level on projection.
- G: Pack between back of canopy and wall if/where required. Tighten/slacken fixing if necessary.

### **STEP 5**

- H: Once canopy is all level, put fixings adjacent to all baffles and along back lower soffit at max 300mm c/c.
- I: Use spirit level to double check (loosen & pack if necessary)



Tel: 01536 446395 Email: [sales@theglazingshop.co.uk](mailto:sales@theglazingshop.co.uk) Web: [www.theglazingshop.co.uk](http://www.theglazingshop.co.uk)

Unit 13, Earlstrees Court, Earlstrees Industrial Estate, Corby, Northamptonshire, NN17 4AX

## STEP 6

J: Bracket to be drilled in centre of flat part at both ends.

K: Offer to correct position (top of edge of bracket to be under soffit) and mark on the wall through pre-drilled holes.

L: With bracket removed drill into brickwork, then fix using 100mm concrete screws, with washer to take cover caps.

M: Fix bracket up to canopy using 70mm wood screws with washer for cover caps. (Repeat for both brackets)

## STEP 7

N: Mark and pre-drill roof of canopy along back of flange at max 600mm centres, using 6.5mm drill bit. Holes to be equally spaced and at same height.

O: Offer roof to soffit – roof lip to overlap with soffit lip edges.

P: Drill (6.5x120xx bit) through pre-drilled holes into brickwork. Fix using 7.5x100mm concrete fixing with washers to receive colour match caps.

## STEP 8

Q: Before fixing tight, packers may be necessary between roof flange and brickwork to prevent canopy going out of level.

R: Silicone mastic seal roof flange/wall and soffit/brickwork in appropriate colour.

S: Cover all visible screw heads with colour matching caps, or lead flash into brickwork and over flange (optional).



the  
**glazing**shop

Tel: 01536 446395 Email: [sales@theglazingshop.co.uk](mailto:sales@theglazingshop.co.uk) Web: [www.theglazingshop.co.uk](http://www.theglazingshop.co.uk)

Unit 13, Earlstrees Court, Earlstrees Industrial Estate, Corby, Northamptonshire, NN17 4AX